

## > OVERSHOT YEDEKLERİ



### BWL / BWLTK OVERSHOT YEDEKLERİ

(PARÇA NO BR-9651)

NO	PARÇA NO	DESCRIPTION	AÇIKLAMA	ADET
1	BR-52986	THRUST BEARING	ALIN RULMANI	1
2	BR-52985	NYLOC NUT	SOMUN	1
3	BR-71447	BWL GREASE FITTING	BWL GRESÖRLÜK	1
4	BR-26904	BWL HEX NUT	BWL SOMUN	1
5	BR-5343772	BWL STEEL BALL	BWL MİSKET	2
6	BR-5345053	BWL COMPRESSION SPRING	BWL MİSKET YAYI	2
7	BR-9651	BWL LIFTING DOG COMPRESSION SPRING	BWL MANDAL YAYI	1
8	BR-9650	BWL LIFTING DOG	BWL MANDAL	2
9	BR-24941	BWL LIFTING DOG SPRING PIN	BWL MANDAL PİMİ	1
10	BR-92073	BWL SPRING PIN	BWL PİM	1
11	BR-5345073	BWL BOLT, LOCKING SLEEVE	BWL KURTARICI CİVATASI	1

### NWL / NWLTK / NWL3 OVERSHOT YEDEKLERİ

(PARÇA NO BR-9652)

NO	PARÇA NO	DESCRIPTION	AÇIKLAMA	ADET
1	BR-52986	THRUST BEARING	ALIN RULMANI	1
2	BR-52985	NYLOC NUT	SOMUN	1
3	BR-71447	WL GREASE FITTING	WL GRESÖRLÜK	1
4	BR-44524	WL HEX NUT	WL SOMUN	1
5	BR-5343772	WL STEEL BALL	WL MİSKET	2
6	BR-9651	WL COMPRESSION SPRING	WL MİSKET YAYI	2
7	BR-5342027	WL LIFTING DOG COMPRESSION SPRING	WL MANDAL YAYI	1
8	BR-5340529	WL LIFTING DOG	WL MANDAL	2
9	BR-42906	NWL LIFTING DOG SPRING PIN	NWL MANDAL PİMİ	1
10	BR-73394	NWL SPRING PIN	NWL PİM	1
11	BR-5345073	WL BOLT, LOCKING SLEEVE	WL KURTARICI CİVATASI	1

### HWL / HWL3 / PWL / PWL3 OVERSHOT YEDEKLERİ

(PARÇA NO BR-9653)

NO	PARÇA NO	DESCRIPTION	AÇIKLAMA	ADET
1	BR-52986	THRUST BEARING	ALIN RULMANI	1
2	BR-52985	NYLOC NUT	SOMUN	1
3	BR-71447	WL GREASE FITTING	WL GRESÖRLÜK	1
4	BR-44524	WL HEX NUT	WL SOMUN	1
5	BR-5343772	WL STEEL BALL	WL MİSKET	2
6	BR-9651	WL COMPRESSION SPRING	WL MİSKET YAYI	2
7	BR-5342027	WL LIFTING DOG COMPRESSION SPRING	WL MANDAL YAYI	1
8	BR-5340529	WL LIFTING DOG	WL MANDAL	2
9	BR-5340527	HWL LIFTING DOG SPRING PIN	HWL MANDAL PİMİ	1
	BR-5340528	PWL LIFTING DOG SPRING PIN	PWL MANDAL PİMİ	1
10	BR-42307	HWL SPRING PIN	HWL PİM	1
	BR-423071	PWL SPRING PIN	PWL PİM	1
11	BR-5345073	WL BOLT, LOCKING SLEEVE	WL KURTARICI CİVATASI	1



## OVERSHOT SPARE KIT OVERSHOT YEDEKLERİ

KAROTİYERLER  
ve YEDEKLERİ



### BWLU OVERSHOT YEDEKLERİ

(PARÇA NO BR-9654)

NO	PARÇA NO	DESCRIPTION	AÇIKLAMA	ADET
1	BR-52986	THRUST BEARING	ALIN RULMANI	1
2	BR-52985	NYLOC NUT	SOMUN	1
3	BR-4668302	BWLU WASHER	BWLU PUL	1
4	BR-46683	BWLU SEAL	BWLU KEÇE	1
5	BR-5345053	WLU CONNECTION SPRING PIN	WLU BAĞLANTI PİMİ	1
6	BR-9651	BWL LIFTING DOG COMPRESSION SPRING	BWL MANDAL YAYI	1
7	BR-9650	BWL LIFTING DOG	BWL MANDAL	2
8	BR-42906	WLU LIFTING DOG SPRING PIN	WLU MANDAL PİMİ	1
9	BR-73394	WLU SPRING PIN	WLU PİM	1

### NWLU OVERSHOT YEDEKLERİ

(PARÇA NO BR-9655)

NO	PARÇA NO	DESCRIPTION	AÇIKLAMA	ADET
1	BR-52986	THRUST BEARING	ALIN RULMANI	1
2	BR-52985	NYLOC NUT	SOMUN	1
3	BR-4630202	NWLU WASHER	NWLU PUL	1
4	BR-46302	NWLU SEAL	NWLU KEÇE	1
5	BR-5345053	WLU CONNECTION SPRING PIN	WLU BAĞLANTI PİMİ	1
6	BR-5342027	WL LIFTING DOG COMPRESSION SPRING	WL MANDAL YAYI	1
7	BR-5340529	WL LIFTING DOG	WL MANDAL	2
8	BR-42906	WLU LIFTING DOG SPRING PIN	WLU MANDAL PİMİ	1
9	BR-73394	WLU SPRING PIN	WLU PİM	1

### HWLU OVERSHOT YEDEKLERİ

(PARÇA NO BR-9656)

NO	PARÇA NO	DESCRIPTION	AÇIKLAMA	ADET
1	BR-52986	THRUST BEARING	ALIN RULMANI	1
2	BR-52985	NYLOC NUT	SOMUN	1
3	BR-4668502	HWLU WASHER	HWLU PUL	1
4	BR-46685	HWLU SEAL	HWLU KEÇE	1
5	BR-5345053	WLU CONNECTION SPRING PIN	WLU BAĞLANTI PİMİ	1
6	BR-5342027	WL LIFTING DOG COMPRESSION SPRING	WL MANDAL YAYI	1
7	BR-5340529	WL LIFTING DOG	WL MANDAL	2
8	BR-42906	WLU LIFTING DOG SPRING PIN	WLU MANDAL PİMİ	1
9	BR-73394	WLU SPRING PIN	WLU PİM	1