

> BWL KAROTİYER YEDEKLERİ



(PARÇA NO BR-0066001)

NO	PARÇA NO	DESCRIPTION	AÇIKLAMA	ADET
1	BR-24913	WL SPEARHEAD POINT	WL ÇAMBAŞI	1
2	BR-24905	WL SPRING PIN	WL ÇAMBAŞI PİMİ	1
3	BR-24914	WL DETENT PLUNGER	WL ÇAMBAŞI SUSTASI	1
4	BR-51141	WL COMPRESSION SPRING	WL ÇAMBAŞI YAYI	2
5	BR-32941	BWL SPRING PIN	BWL BAŞLIK MUHAFAZA PİMİ	2
6	BR-5341932	WL BOLT	WL BAŞLIK VİDASI	2
7	BR-5343180	BWL LATCH COMPRESSION SPRING	BWL BAŞLIK MUHAFAZA YAYI	1
8	BR-036417	BWL LATCH	BWL MANDAL	4
9	BR-036418	BWL LINK	BWL MANDAL DESTEĞİ	4
10	BR-32944	BWL SPRING PIN	BWL MANDAL PİMİ	2
11	BR-26374	WL STEEL BALL	WL ÇELİK MİSKET	1
12	BR-26380	WL LANDING INDICATOR BUSHING	WL PLASTİK MİSKET YUVASI	2
13	BR-036421	BWL LANDING SHOULDER	BWL BAŞLIK DURDURUCU BİLEZİK	1
14	BR-44601	BWL HEX NUT	BWL BOY AYAR MİLİ SOMUNU	1
15	BR-44208	BWL SHUT OFF VALVE, HARD	BWL LASTİK	4
16	BR-42030	BWL THRUST/HANGER BEARING	BWL ALIN/ZARFLI RULMAN	2
17	BR-42336	BWL SPINDLE BUSHING	BWL RULMAN BASKI SOMUNU	1
18	BR-013144	BWL NYLOC NUT	BWL BASKI YAYI SOMUNU	1
19	BR-71447	GREASE FITTING	GRESÖRLÜK	2
20	BR-42831	BWL STOP RING	BWL KEÇİR YUVASI RİNGİ	2
21	BR-03487	BWL CORE LIFTER	BWL KEÇİR	20
22	BR-42830	BWL CORE LIFTER CASE	BWL KEÇİR YUVASI	4
23	BR-42345	BWL LANDING RING	BWL DURDURUCU BİLEZİK	2
24	BR-44406	BWL INNER TUBE STABILIZER	BWL İÇ TÜP MERKEZLEYİCİ SARI	2



(PARÇA NO BR-0066002)

NO	PARÇA NO	DESCRIPTION	AÇIKLAMA	ADET
1	BR-24913	WL SPEARHEAD POINT	WL ÇAMBAŞI	1
2	BR-24905	WL SPRING PIN	WL ÇAMBAŞI PİMİ	2
3	BR-24914	WL DETENT PLUNGER	WL ÇAMBAŞI SUSTASI	1
4	BR-51141	WL COMPRESSION SPRING	WL ÇAMBAŞI YAYI	1
5	BR-42305	NWL SPRING PIN	NWL BAŞLIK MUHAFAZA PİMİ	2
6	BR-5341932	WL BOLT	WL BAŞLIK VİDASI	2
7	BR-5343812	NWL LATCH COMPRESSION SPRING	NWL BAŞLIK MUHAFAZA YAYI	1
8	BR-014816	NWL LATCH	NWL MANDAL	4
9	BR-036454	NWL LINK	NWL MANDAL DESTEĞİ	4
10	BR-42548	NWL SPRING PIN	NWL MANDAL PİMİ	2
11	BR-26374	WL STEEL BALL	WL ÇELİK MİSKET	1
12	BR-26380	WL LANDING INDICATOR BUSHING	WL PLASTİK MİSKET YUVASI	2
13	BR-036009	NWL LANDING SHOULDER	NWL BAŞLIK DURDURUCU BİLEZİK	1
14	BR-42885	NWL HEX NUT	NWL BOY AYAR MİLİ SOMUNU	1
15	BR-44209	NWL SHUT OFF VALVE, HARD	NWL LASTİK	4
16	BR-81298	NWL HANGER BEARING	NWL ZARFLI RULMAN	1
17	BR-42889	NWL SPINDLE BUSHING	NWL RULMAN BASKI SOMUNU	1
18	BR-42312	NWL THRUST BEARING	NWL ALIN RULMANI	1
19	BR-22918	NWL NYLOC NUT	NWL BASKI YAYI SOMUNU	1
20	BR-71447	GREASE FITTING	GRESÖRLÜK	2
21	BR-42893	NWL STOP RING	NWL KEÇİR YUVASI RİNGİ	2
22	BR-03488	NWL CORE LIFTER	NWL KEÇİR	20
23	BR-42892	NWL CORE LIFTER CASE	NWL KEÇİR YUVASI	4
24	BR-42897	NWL LANDING RING	NWL DURDURUCU BİLEZİK	2
25	BR-44407	NWL INNER TUBE STABILIZER	NWL İÇ TÜP MERKEZLEYİCİ SARI	2

> HWL KAROTİYER YEDEKLERİ



(PARÇA NO BR-0066003)

NO	PARÇA NO	DESCRIPTION	AÇIKLAMA	ADET
1	BR-24913	WL SPEARHEAD POINT	WL ÇAMBAŞI	1
2	BR-24905	WL SPRING PIN	WL ÇAMBAŞI PİMİ	2
3	BR-24914	WL DETENT PLUNGER	WL ÇAMBAŞI SUSTASI	1
4	BR-51141	WL COMPRESSION SPRING	WL ÇAMBAŞI YAYI	1
5	BR-42524	HWL SPRING PIN	HWL BAŞLIK MUHAFAZA PİMİ	2
6	BR-5341932	WL BOLT	WL BAŞLIK VİDASI	2
7	BR-5343619	HWL LATCH COMPRESSION SPRING	HWL BAŞLIK MUHAFAZA YAYI	1
8	BR-014818	HWL LATCH	HWL MANDAL	4
9	BR-036216	HWL LINK	HWL MANDAL DESTEĞİ	4
10	BR-42305	HWL SPRING PIN	HWL MANDAL PİMİ	2
11	BR-26374	WL STEEL BALL	WL ÇELİK MİSKET	1
12	BR-26380	WL LANDING INDICATOR BUSHING	WL PLASTİK MİSKET YUVASI	2
13	BR-014958	HWL LANDING SHOULDER	HWL BAŞLIK DURDURUCU BİLEZİK	1
14	BR-44574	HWL HEX NUT	HWL BOY AYAR MİLİ SOMUNU	1
15	BR-34513	HWL SHUT OFF VALVE, HARD	HWL LASTİK	4
16	BR-42312	HWL HANGER BEARING	HWL ZARFLI RULMAN	2
17	BR-52234	HWL SPINDLE BUSHING	HWL RULMAN BASKI SOMUNU	1
18	BR-42528	HWL THRUST BEARING	HWL ALIN RULMANI	1
19	BR-013465	HWL NYLOC NUT	HWL BASKI YAYI SOMUNU	1
20	BR-71447	GREASE FITTING	GRESÖRLÜK	2
21	BR-52238	HWL STOP RING	HWL KEÇİR YUVASI RİNGİ	2
22	BR-03489	HWL CORE LIFTER	HWL KEÇİR	20
23	BR-52237	HWL CORE LIFTER CASE	HWL KEÇİR YUVASI	4
24	BR-52242	HWL LANDING RING	HWL DURDURUCU BİLEZİK	2
25	BR-44408	HWL INNER TUBE STABILIZER	HWL İÇ TÜP MERKEZLEYİCİ SARI	2



(PARÇA NO BR-0066004)


NO	PARÇA NO	DESCRIPTION	AÇIKLAMA	ADET
1	BR-24913	WL SPEARHEAD POINT	WL ÇAMBAŞI	1
2	BR-24905	WL SPRING PIN	WL ÇAMBAŞI PİMİ	2
3	BR-24914	WL DETENT PLUNGER	WL ÇAMBAŞI SUSTASI	1
4	BR-51141	WL COMPRESSION SPRING	WL ÇAMBAŞI YAYI	1
5	BR-42524	HWL SPRING PIN	HWL BAŞLIK MUHAFAZA PİMİ	2
6	BR-5341932	WL BOLT	WL BAŞLIK VİDASI	2
7	BR-5343619	HWL LATCH COMPRESSION SPRING	HWL BAŞLIK MUHAFAZA YAYI	1
8	BR-014818	HWL LATCH	HWL MANDAL	4
9	BR-036216	HWL LINK	HWL MANDAL DESTEĞİ	4
10	BR-42305	HWL SPRING PIN	HWL MANDAL PİMİ	2
11	BR-5340152	WL STEEL BALL	WL ÇELİK MİSKET	1
12	BR-26380	WL LANDING INDICATOR BUSHING	WL PLASTİK MİSKET YUVASI	1
13	BR-5343797	PWL LANDING SHOULDER	PWL BAŞLIK DURDURUCU BİLEZİK	1
14	BR-44574	HWL HEX NUT	HWL BOY AYAR MİLİ SOMUNU	1
15	BR-5340308	PWL SHUT OFF VALVE, HARD	PWL LASTİK	4
16	BR-4252901	PWL HANGER BEARING	PWL ALIN RULMANI	2
17	BR-5340794	PWL SPINDLE BUSHING	PWL RULMAN BASKI SOMUNU	1
18	BR-71447	GREASE FITTING	GRESÖRLÜK	2
19	BR-42528	PWL THRUST BEARING	PWL ZARFLI RULMAN	1
20	BR-033062	PWL NYLOC NUT	PWL BASKI YAYI SOMUNU	1
21	BR-62161	PWL STOP RING	PWL KEÇİR YUVASI RİNGİ	2
22	BR-62162	PWL CORE LIFTER	PWL KEÇİR	20
23	BR-25172	PWL CORE LIFTER CASE	PWL KEÇİR YUVASI	4
24	BR-5343814	PWL LANDING RING	PWL DURDURUCU BİLEZİK	2
25	BR-44923	PWL INNER TUBE STABILIZER	PWL İÇ TÜP MERKEZLEYİCİ SARI	2

> BWLU KAROTİYER YEDEKLERİ



(PARÇA NO BR-0066005)

NO	PARÇA NO	DESCRIPTION	AÇIKLAMA	ADET
1	BR-534431	BWLU SPEARHEAD POINT	BWLU ÇAMBAŞI	1
2	BR-44691	BWLU HEX NUT	BWLU ÇAMBAŞI AYAR SOMUNU	1
3	BR-46603	BWLU PUMP-IN SEAL WASHER	BWLU LASTİK PUL	2
4	BR-46683	BWLU PUMP-IN SEAL	BWLU LASTİK KEÇE	2
5	BR-44619	BWLU O-RING	BWLU O-RING	4
6	BR-32941	BWL SPRING PIN	BWL BAŞLIK MUHAFAZA PİMİ	2
7	BR-5341933	BWLU BOLT	BWLU BAŞLIK VİDASI	2
8	BR-5341836	BWLU LATCH COMPRESSION SPRING	BWLU BAŞLIK MUHAFAZA YAYI	1
9	BR-0364181	BWLU LINK	BWLU MANDAL DESTEĞİ	4
10	BR-0364171	BWLU LATCH	BWLU MANDAL	4
11	BR-329441	BWLU SPRING PIN	BWLU MANDAL PİMİ	1
12	BR-263741	BWLU STEEL BALL	BWLU ÇELİK MİSKET	1
13	BR-5343905	BWLU LANDING INDICATOR BUSHING	BWLU PLASTİK MİSKET YUVASI	4
14	BR-0364211	BWLU LANDING SHOULDER	BWLU BAŞLIK DURDURUCU BİLEZİK	2
15	BR-44601	BWL HEX NUT	BWL BOY AYAR MİLİ SOMUNU	1
16	BR-44208	BWL SHUT OFF VALVE, HARD	BWL LASTİK	4
17	BR-42030	BWL THRUST/HANGER BEARING	BWL ALIN/ZARFLI RULMAN	1
18	BR-42336	BWL SPINDLE BUSHING	BWL RULMAN BASKI SOMUNU	1
19	BR-013144	BWL NYLOC NUT	BWL BASKI YAYI SOMUNU	1
20	BR-71447	GREASE FITTING	GRESÖRLÜK	2
21	BR-42831	BWL STOP RING	BWL KEÇİR YUVASI RİNGİ	2
22	BR-42342	BWL CORE LIFTER	BWL KEÇİR	20
23	BR-42830	BWL CORE LIFTER CASE	BWL KEÇİR YUVASI	4
24	BR-42345	BWL LANDING RING	BWL DURDURUCU BİLEZİK	2
25	BR-44406	BWL INNER TUBE STABILIZER	BWL İÇ TÜP MERKEZLEYİCİ SARI	2



(PARÇA NO BR-0066006)

NO	PARÇA NO	DESCRIPTION	AÇIKLAMA	ADET
1	BR-534433	NWLU SPEARHEAD POINT	NWLU ÇAMBAŞI	1
2	BR-42895	NWLU HEX NUT	NWLU ÇAMBAŞI AYAR SOMUNU	1
3	BR-46392	NWLU PUMP-IN SEAL WASHER	NWLU LASTİK PUL	2
4	BR-46302	NWLU PUMP-IN SEAL	NWLU LASTİK KEÇE	4
5	BR-42985	NWLU O-RING	NWLU O-RING	4
6	BR-42305	NWL SPRING PIN	NWL BAŞLIK MUHAFAZA PİMİ	2
7	BR-5341932	NWL BOLT	NWL BAŞLIK VİDASI	2
8	BR-5343136	NWL LATCH COMPRESSION SPRING	NWL BAŞLIK MUHAFAZA YAYI	1
9	BR-014817	NWL LINK	NWL MANDAL DESTEĞİ	4
10	BR-014816	NWL LATCH	NWL MANDAL	4
11	BR-42307	NWL SPRING PIN	NWL MANDAL PİMİ	1
12	BR-263741	NWLU STEEL BALL	NWLU ÇELİK MİSKET	1
13	BR-5343906	NWLU LANDING INDICATOR BUSHING	NWLU PLASTİK MİSKET YUVASI	4
14	BR-033009	NWL LANDING SHOULDER	NWL BAŞLIK DURDURUCU BİLEZİK	2
15	BR-42885	NWL HEX NUT	NWL BOY AYAR MİLİ SOMUNU	1
16	BR-44209	NWL SHUT OFF VALVE, HARD	NWL LASTİK	4
17	BR-81298	NWL HANGER BEARING	NWL ALIN RULMANI	1
18	BR-42889	NWL SPINDLE BUSHING	NWL RULMAN BASKI SOMUNU	1
19	BR-42312	NWL THRUST BEARING	NWL ZARFLI RULMAN	1
20	BR-22918	NWL NYLOC NUT	NWL BASKI YAYI SOMUNU	1
21	BR-71447	GREASE FITTING	GRESÖRLÜK	2
22	BR-42893	NWL STOP RING	NWL KEÇİR YUVASI RİNGİ	2
23	BR-42894	NWL CORE LIFTER	NWL KEÇİR	20
24	BR-42892	NWL CORE LIFTER CASE	NWL KEÇİR YUVASI	4
25	BR-42897	NWL LANDING RING	NWL DURDURUCU BİLEZİK	2
26	BR-44407	NWL INNER TUBE STABILIZER	NWL İÇ TÜP MERKEZLEYİCİ SARI	2



NWLTK KAROTİYER YEDEKLERİ



(PARÇA NO BR-0066007)

NO	PARÇA NO	DESCRIPTION	AÇIKLAMA	ADET
1	BR-24913	WL SPEARHEAD POINT	WL ÇAMBAŞI	1
2	BR-24905	WL SPRING PIN	WL ÇAMBAŞI PİMİ	2
3	BR-24914	WL DETENT PLUNGER	WL ÇAMBAŞI SUSTASI	1
4	BR-51141	WL COMPRESSION SPRING	WL ÇAMBAŞI YAYI	1
5	BR-24905	WL SPRING PIN	WL ÇAMBAŞI PİMİ	2
6	BR-5341932	WL BOLT	WL BAŞLIK VİDASI	2
7	BR-5343812	NWL LATCH COMPRESSION SPRING	NWL BAŞLIK MUHAFAZA YAYI	1
8	BR-014816	NWL LATCH	NWL MANDAL	4
9	BR-036454	NWL LINK	NWL MANDAL DESTEĞİ	4
10	BR-42548	NWL SPRING PIN	NWL MANDAL PİMİ	2
11	BR-26374	WL STEEL BALL	WL ÇELİK MİSKET	1
12	BR-26380	WL LANDING INDICATOR BUSHING	WL PLASTİK MİSKET YUVASI	2
13	BR-036026	NWL LANDING SHOULDER	NWL BAŞLIK DURDURUCU BİLEZİK	1
14	BR-24885	NWL HEX NUT	NWL BOY AYAR MİLİ SOMUNU	1
15	BR-44209	NWL SHUT OFF VALVE, HARD	NWL LASTİK	4
16	BR-81298	NWL HANGER BEARING	NWL ALIN RULMANI	1
17	BR-42889	NWL SPINDLE BUSHING	NWL RULMAN BASKI SOMUNU	1
18	BR-42312	NWL THRUST BEARING	NWL ZARFLI RULMAN	1
19	BR-22918	NWL NYLOC NUT	NWL BASKI YAYI SOMUNU	1
20	BR-71447	GREASE FITTING	GRESÖRLÜK	2
21	BR-92210	NWLTK STOP RING	NWLTK KEÇİR YUVASI RİNGİ	2
22	BR-16416	NWLTK CORE LIFTER	NWLTK KEÇİR	20
23	BR-92209	NWLTK CORE LIFTER CASE	NWLTK KEÇİR YUVASI	4
24	BR-92214	NWLTK LANDING RING	NWLTK DURDURUCU BİLEZİK	2
25	BR-34812	NWLTK INNER TUBE STABILIZER	NWLTK İÇ TÜP MERKEZLEYİCİ SARI	2



(PARÇA NO BR-0066008)

NO	PARÇA NO	DESCRIPTION	AÇIKLAMA	ADET
1	BR-24913	WL SPEARHEAD POINT	WL ÇAMBAŞI	1
2	BR-24905	WL SPRING PIN	WL ÇAMBAŞI PİMİ	2
3	BR-24914	WL DETENT PLUNGER	WL ÇAMBAŞI SUSTASI	1
4	BR-51141	WL COMPRESSION SPRING	WL ÇAMBAŞI YAYI	1
5	BR-42305	NWL SPRING PIN	NWL BAŞLIK MUHAFAZA PİMİ	2
6	BR-5341932	WL BOLT	WL BAŞLIK VİDASI	2
7	BR-5343812	NWL LATCH COMPRESSION SPRING	NWL BAŞLIK MUHAFAZA YAYI	1
8	BR-036454	NWL LINK	NWL MANDAL DESTEĞİ	4
9	BR-014816	NWL LATCH	NWL MANDAL	4
10	BR-42548	NWL SPRING PIN	NWL MANDAL PİMİ	2
11	BR-26374	WL STEEL BALL	WL ÇELİK MİSKET	1
12	BR-26380	WL LANDING INDICATOR BUSHING	WL PLASTİK MİSKET YUVASI	2
13	BR-036009	NWL LANDING SHOULDER	NWL BAŞLIK DURDURUCU BİLEZİK	1
14	BR-24885	NWL HEX NUT	NWL BOY AYAR MİLİ SOMUNU	1
15	BR-44209	NWL SHUT OFF VALVE, HARD	NWL LASTİK	4
16	BR-81298	NWL HANGER BEARING	NWL ALIN RULMANI	1
17	BR-42889	NWL SPINDLE BUSHING	NWL RULMAN BASKI SOMUNU	1
18	BR-42312	NWL THRUST BEARING	NWL ZARFLI RULMAN	1
19	BR-22918	NWL NYLOC NUT	NWL BASKI YAYI SOMUNU	1
20	BR-71447	GREASE FITTING	GRESÖRLÜK	2
21	BR-62530	NWL3 STOP RING	NWL3 KEÇİR YUVASI RİNGİ	2
22	BR-62531	NWL3 CORE LIFTER	NWL3 KEÇİR	20
23	BR-62529	NWL3 CORE LIFTER CASE	NWL3 KEÇİR YUVASI	4
24	BR-62134	NWL3 O-RING	NWL3 O-RİNG	5
25	BR-42897	NWL LANDING RING	NWL DURDURUCU BİLEZİK	2
26	BR-44407	NWL INNER TUBE STABILIZER	NWL İÇ TÜP MERKEZLEYİCİ SARI	2

> HWL3 KAROTİYER YEDEKLERİ



(PARÇA NO BR-0066009)

NO	PARÇA NO	DESCRIPTION	AÇIKLAMA	ADET
1	BR-24913	WL SPEARHEAD POINT	WL ÇAMBAŞI	1
2	BR-24905	WL SPRING PIN	WL ÇAMBAŞI PİMİ	2
3	BR-24914	WL DETENT PLUNGER	WL ÇAMBAŞI SUSTASI	1
4	BR-51141	WL COMPRESSION SPRING	WL ÇAMBAŞI YAYI	1
5	BR-42524	HWL SPRING PIN	HWL BAŞLIK MUHAFAZA PİMİ	2
6	BR-5341932	WL BOLT	WL BAŞLIK VİDASI	2
7	BR-5343619	HWL LATCH COMPRESSION SPRING	HWL BAŞLIK MUHAFAZA YAYI	1
8	BR-036216	HWL LINK	HWL MANDAL DESTEĞİ	4
9	BR-014818	HWL LATCH	HWL MANDAL	4
10	BR-42305	HWL SPRING PIN	HWL MANDAL PİMİ	2
11	BR-26374	WL STEEL BALL	WL ÇELİK MİSKET	1
12	BR-26380	WL LANDING INDICATOR BUSHING	WL PLASTİK MİSKET YUVASI	2
13	BR-014958	HWL LANDING SHOULDER	HWL BAŞLIK DURDURUCU BİLEZİK	1
14	BR-44574	HWL HEX NUT	HWL BOY AYAR MİLİ SOMUNU	1
15	BR-34513	HWL SHUT OFF VALVE, HARD	HWL LASTİK	4
16	BR-42312	HWL HANGER BEARING	HWL ALIN RULMANI	2
17	BR-52234	HWL SPINDLE BUSHING	HWL RULMAN BASKI SOMUNU	1
18	BR-42528	HWL THRUST BEARING	HWL ZARFLI RULMAN	1
19	BR-013465	HWL NYLOC NUT	HWL BASKI YAYI SOMUNU	1
20	BR-71447	GREASE FITTING	GRESÖRLÜK	2
21	BR-62515	HWL3 STOP RING	HWL3 KEÇİR YUVASI RİNGİ	2
22	BR-62516	HWL3 CORE LIFTER	HWL3 KEÇİR	20
23	BR-62514	HWL3 CORE LIFTER CASE	HWL3 KEÇİR YUVASI	4
24	BR-02651	HWL3 PISTON O-RING	HWL3 PİSTON O-RİNG	5
25	BR-52242	HWL LANDING RING	HWL DURDURUCU BİLEZİK	2
26	BR-44408	HWL INNER TUBE STABILIZER	HWL İÇ TÜP MERKEZLEYİCİ SARI	2



PWL3 KAROTİYER YEDEKLERİ

KAROTİYERLER
ve YEDEKLERİ



(PARÇA NO BR-0066010)

NO	PARÇA NO	DESCRIPTION	AÇIKLAMA	ADET
1	BR-24913	WL SPEARHEAD POINT	WL ÇAMBAŞI	1
2	BR-24905	WL SPRING PIN	WL ÇAMBAŞI PİMİ	2
3	BR-24914	WL DETENT PLUNGER	WL ÇAMBAŞI SUSTASI	1
4	BR-51141	WL COMPRESSION SPRING	WL ÇAMBAŞI YAYI	1
5	BR-42524	HWL SPRING PIN	HWL BAŞLIK MUHAFAZA PİMİ	2
6	BR-5341932	WL BOLT	WL BAŞLIK VİDASI	2
7	BR-5343619	HWL LATCH COMPRESSION SPRING	HWL BAŞLIK MUHAFAZA YAYI	1
8	BR-036216	HWL LINK	HWL MANDAL DESTEĞİ	4
9	BR-014818	HWL LATCH	HWL MANDAL	4
10	BR-42305	HWL SPRING PIN	HWL MANDAL PİMİ	2
11	BR-26374	WL STEEL BALL	WL ÇELİK MİSKET	1
12	BR-26380	WL LANDING INDICATOR BUSHING	WL PLASTİK MİSKET YUVASI	1
13	BR-5343797	PWL LANDING SHOULDER	PWL BAŞLIK DURDURUCU BİLEZİK	1
14	BR-73475	HWL HEX NUT	HWL BOY AYAR MİLİ SOMUNU	1
15	BR-5340308	PWL SHUT OFF VALVE, HARD	PWL LASTİK	4
16	BR-4252901	PWL HANGER BEARING	PWL ZARFLI RULMAN	2
17	BR-5340794	PWL SPINDLE BUSHING	PWL RULMAN BASKI SOMUNU	1
18	BR-71447	GREASE FITTING	GRESÖRLÜK	2
19	BR-42528	PWL THRUST BEARING	PWL ALIN RULMANI	1
20	BR-013062	PWL NYLOC NUT	PWL BASKI YAYI SOMUNU	1
21	BR-62176	PWL3 STOP RING	PWL3 KEÇİR YUVASI RİNGİ	2
22	BR-62177	PWL3 CORE LIFTER	PWL3 KEÇİR	20
23	BR-62160	PWL3 CORE LIFTER CASE	PWL3 KEÇİR YUVASI	4
24	BR-62178	PWL3 PISTON O-RING	PWL3 PİSTON O-RİNG	1
25	BR-5343814	PWL LANDING RING	PWL DURDURUCU BİLEZİK	1
26	BR-44923	PWL INNER TUBE STABILIZER	PWL İÇ TÜP MERKEZLEYİCİ SARI	1